

Jacobs to Cummins				Cummins to Jacobs		
#	Description	Jacobs #	Cummins #	Description	Cummins #	Jacobs #
1	CROSSHEAD,EXHAUST	1003	3871200	SCREW	199225	2969
2	SPRING,CONTROL VALVE	1012	3871201	WASHER,BEARING LOCK*	217788	2514
3	SCREW,RKR LEVER ADJUSTING	1015	3871202	CONTROL,ENG BRAKE CABIN*	3042594	3965
4	MASTER PISTON	1017	3871203	STUD	3063529	15633
5	BALL	1021	3871204	STUD	3063530	15635
6	SPRING,SLAVE PISTON	1022	3871205	STUD	3063531	15637
7	RING,RETAINING	1023	3871206	NUT,REGULAR HEXAGON*	3063532	15901
8	NUT,HEX JAM	1026	3871207	SPACER,MOUNTING*	3063533	1234
9	WASHER	1030	3871208	STUD*	3063546	1199
10	SET SCREW	1031	3871209	STUD*	3063547	13542
11	CAPSCREW	1033	3871210	STUD*	3063548	13540
12	WASHER,OIL TUBE CAPSCREW	1049	3871212	SCREW,HEXAGON HEAD CAP*	3063550	12292
13	CAPSCREW	1050	3871213	TAG,INSTRUCTION*	3063571	15908
14	SEAL RING	1051	3871214	BRAKE,ENGINE	3065137	16007
15	STUD,MOUNTING	1055	3871215	HARNESS,WIRING	3065171	17416
16	SEAL RING, UPPER	1081	3871216	BRAKE,ENGINE*	3069111	16656
17	SEAL,RECTANGULAR RING	1082	4026537	HARNESS,WIRING	3071205	18055
18	SEAL,RECTANGULAR RING	1083	3871218	CROSSHEAD,VALVE*	3071207	19805
19	WASHER,OIL TUBE	1091	3871219	CROSSHEAD,VALVE	3071208	19807
20	NUT,HEX	1094	3871220	SCREW,HEXAGON HEAD SET*	3072887	16627
21	GRINDING GAGE	1153	3871221	BRAKE,ENGINE	3073771	17421
22	BRACKET,SWITCH MOUNTING	1178	3871222	BRAKE,ENGINE	3073772	17423
23	ARM,SWITCH ACUTATING	1179	3871223	CROSSHEAD ASSEMBLY	3073952	17302
24	COVER,SWITCH	1180	3871224	CONNECTOR,ELECTRICAL*	3073972	17366
25	NUT,HEX	1181	3871225	CONNECTOR,ELECTRICAL*	3073974	17367
26	SCREW,HEX HEAD MACHINE	1182	3871226	TUBE, LUBE OIL SUPPLY*	3073975	17352
27	CONTROL VALVE COVER	1189	3871227	UNION,MALE*	3073976	17186
28	STUD*	1199	3063546	WASHER,SEALING	3073977	17184
29	SPOOL ASSY.,CONTROL VALVE	1200	3871228	SCREW,CAPTIVE WASHER CAP	3074534	17958
30	SPACER,AIR INTAKE	1226	3871229	BRAKE,ENGINE	3079659	17285
31	CONNECTOR,AIR OUTLET	1229	3871230	BRAKE,ENGINE	3079660	17287
32	STUD,MACHINED ASSY.	1232	3871231	HARNESS,WIRING	3080422	18687
33	SPACER,MOUNTING*	1234	3063533	SCREW,HEXAGON HEAD SET*	3080759	18929
34	SPACER,COMP. REL. LEVER	1235	3871232	BRAKE,ENGINE	3084581	19396
35	SPACER,FAN BRACKET	1236	3871233	BRAKE,ENGINE	3084582	19397
36	CROSSHEAD,EXHAUST	1239	3871234	SPACER,ROCKER LEVER COVER*	3084583	19064
37	GASKET,BRAKE HOUSING	1243	3871235	HARNESS,WIRING	3095433	20364
38	SCREW,TAPPING	1244	3871236	EXISB EXHAUST BRAKE ASSY	3099084	24881
39	BUTTON HEAD SCREW	1265	3871238	EXTARDE ASSEMBLY ISB/H	3099088	24232
40	SPACER GRP, MANIFOLD CONN	1271	3871239	EXTARDE ASSEMBLY ISB/F	3099091	24666
41	AIR INTAKE MANIFOLD CONN	1273	3871240	GASKET,EXH OUT CONNECTION	3099094	24764
42	NUT	1276	3871241	Brake Housing 411D Front 12v s/l	3103430	32620
43	RETAINER,SLAVE PISTON SPG	1289	3871242	Brake Housing 411D Rear 12v s/l	3103431	32621
44	SWITCH,ON/OFF - DASH CONT	1304	3871243	BRAKE,ENGINE*	3166308	22600
45	PLATE,ON/OFF SWITCH	1305	3871244	BRAKE,ENGINE*	3166392	21464
46	EXTENSION,OIL TUBE	1422	3871245	SEAL,GROMMET*	3251588	10180
47	SLAVE PISTON	1484	3871246	BRAKE,ENGINE	3254989	18267
48	SLAVE PISTON (SHORT)	1486	3871247	BRAKE,ENGINE*	3255154	24016

#	Description	Jacobs #	Cummins #	Description	Cummins #	Jacobs #
49	CAPSCREW	1492	3871248	CONTROL,ENG BRAKE ENGINE*	3255197	22677
50	TAB.QUICK DISCONNECT	1512	3871249	WIRE, GROUND*	3255804	24523
51	SPRING,CONTROL VLVE INNER	1518	3871250	VALVE,SOLENOID	3284523	20578
52	SPRING,CONTROL VALVE STOP	1519	3871251	EXB59 UK EXHAUST BRAKE KIT	3284540	25037
53	CLAMP,SWITCH	1531	3871252	SPACER,ROCKER LEVER COVER*	3406906	22687
54	DIODE	1534	3871253	WASHER,SEALING*	3406909	24967
55	SCREW,ROUND HEAD MACHINE	1537	3871254	CLIP	3406919	20910
56	WASHER	1538	3871255	HARNESS,WIRING*	3411336	24661
57	SETSCREW	1549	3871256	BRAKE,ENGINE*	3411465	25164
58	SCREW,ASSEMBLY	1558	3871257	BRAKE,ENGINE KIT	3411467	25160
59	LOCK WASHER	1559	3871258	BRAKE,SERVICE	3411469	25162
60	NUT	1713	3871259	SCREW,ADJUSTING	3411473	25166
61	BUTTON HEAD SCREW	1722	3871260	COVER,CONTROL VALVE	3412330	26170
62	RECEPTACLE	1955	3871680	LEVER,ENGINE BRAKE	3413098	26554
63	RECEPTACLE	2014	3871681	Brake Lever Sub-Assembly	3413127	26473
64	NUT,REGULAR HEXAGON JAM	2157	4015691	PISTON,ENGINE BRAKE SLAVE	3413128	26927
65	GASKET	2164	3871261	VALVE,CHECK	3413129	26395
66	CONNECTOR,OIL	2235	4015695	SPRING,COMPRESSION	3413130	26397
67	SEAL RING	2236	3871682	COVER,ACTUATOR	3413131	26475
68	CAPSCREW,SOCKET HEAD	2375	3871262	RING,RETAINING	3413132	26555
69	CLAMP	2376	3871263	BUSHING	3413133	25965
70	HARNESS,SOLENOID	2390	3871264	BRAKE,ENGINE	3418356	20256
71	WASHER,BEARING LOCK*	2514	217788	NUT,REGULAR HEXAGON JAM	3679921	22061
72	GASKET (3 PACKAGED)	2610	4025001	COVER,ACTUATOR	3680933	25141
73	STUD,MOUNTING	2856	3871267	BODY,ENGINE BRAKE VALVE	3680937	25057
74	SWITCH GRP.,TOGGLE	2957	3871268	HARNESS,WIRING	3681579	26921
75	PLATE, SWITCH	2959	3871265	MANIFOLD ASSEMBLY	3682343	30365
76	SCREW	2969	199225	ISB-TMVO CECO EX BRAKE KIT	3800352	25272
77	TOGGEL SWITCH GROUP	2970	3871594	EXH BK ASSY ISB-TMVO CECO	3800354	25216
78	NUT.HOLD DOWN	3073	3871269	GROUP, DASH SWITCH	3800359	25268
79	SPACER,END UNIT (UPPER)	3074	4015716	EXHAUST BRAKE KIT EXISC	3800372	25566
80	TUBE ASSY.,OIL SUPPLY	3077	3871270	GASKET GROUP, EXISC	3800374	25433
81	TEE,MALE PIPE	3079	3871271	ISB/F EX BRAKE KIT SPARTAN	3800386	25628
82	FEELER GAGE .018 INCH	3087	3871272	EXISB EXHAUST BRAKE KIT	3800387	25637
83	TEE,FEMALE PIPE	3096	3871273	EXHAUST BK KIT ISC/H	3800388	25641
84	MASTER PISTON	3106	3871274	EXHAUST BRAKE KIT ISC/F	3800389	25642
85	SPRING,MASTER PISTON	3107	3871275	EXHAUST BRAKE GROUP EXISC	3800392	25565
86	SPRING,CONTROL VALVE	3109	3871276	EXHAUST BRAKE KIT ISC/H	3800414	25613
87	STUD,ROCKER COVER	3114	3871277	EXHAUST BRAKE KIT ISC/F	3800415	25614
88	STUD,MOUNTING	3122	3871278	EXHAUST BRAKE GROUP	3800416	25615
89	WASHER,CYLINDER HEAD STUD	3127	3871279	EXHAUST BRAKE GROUP ISC/F	3800417	25616
90	SEAL,RING	3130	3871280	EXTARDEK KIT MODEL EXISB	3800441	24923
91	TUBE ASSY., OIL SUPPLY	3216	3871281	ISB/H EXTARDEK KIT	3800442	25044
92	SPACER,FAN BRACKET	3251	3871283	ISB/F EXTARDEK KIT	3800443	25045
93	SHAFT,COMPRESSIN RELIEF	3254	3871284	KIT,ENGINE BRAKE	3800765	22695
94	RECEPTACLE,QUICK DISCONN	3278	3871285	ISB-TMVO EXH BRAKE KIT CECO	3800780	28527
95	NUT,HEX #6-32	3306	3871287	EXH BRAKE GROUP ISB-TMVO MO	3800791	28540
96	MASTER PISTON	3327	3871288	ISB-TMVO EXH BRAKE KIT MOPAR	3800792	28587
97	SPRING,MASTER PISTON	3328	3871289	ISB/C EXH BRAKE KIT MONACO	3800869	28730

#	Description	Jacobs #	Cummins #	Description	Cummins #	Jacobs #
98	MASTER PISTON	3329	3871290	KIT, MODEL 490 TUNE UP	3800917	26303
99	POSITIONER,VALVE SPRING	3402	3871291	EXTARDER KIT MOD EXB59	3802671	19961
100	SPRING,CONTROL VALVE	3410	3871294	EXHAUST BRAKE KIT EXC83	3802672	19963
101	PLATE, DASH SWITCH	3585	3871302	EXTARDER KIT MOD EXB59	3802816	21780
102	SWITCH	3586	3871303	EXTARDER GROUP MOD EXB59	3803905	20197
103	SWITCH GRP	3590	3871304	KIT,BRAKE SWITCH	3803906	19432
104	SWITCH,HYDRAULIC	3591	3871305	KIT, BRAKE SWITCH	3803908	20395
105	SHELL	3592	3871306	KIT,AIR CONTROL	3803910	20904
106	SLEEVE	3593	3871307	KIT, ENGINE CONTROL	3803911	19429
107	TERMINAL	3594	3871308	EXTARDER GROUP MOD EXC83	3803913	20200
108	SCREW,INJ RKR LEVER ADJ	3678	3871310	SET,EXHAUST BRAKE	3803914	19599
109	TUBE,SHRINK	3707	3871311	KIT,WIRING HARNESS	3803918	24929
110	TUBE,SHRINK	3708	3871312	404BG 12VDC STANDARD KIT	3804575	21360
111	NUT, HEX JAM 3/8-24	3720	3871313	404BG 24 VDC S/L BASE KIT	3804576	21361
112	ASSEMBLY,SUPPLY HOUSING	3725	4015705	404BG VDC D/L STANDRD KIT	3804577	21362
113	ASSEMBLY,DRONE HOUSING	3726	4015706	404BG/D 12VDC SPECIAL KIT	3804578	21363
114	SUPPORT,HOUSING	3728	4015713	404BG/D VDC S/L SPEC. KIT	3804579	21364
115	SET SCREW	3748	3871314	404BG/D 24VDC D/L SPEC KT	3804580	21365
116	CAPSCREW	3749	3871315	404D 12 VDC BASE KIT	3804581	21367
117	SPACER,END UNIT (LOWER)	3752	4015717	404D 24VDC S/L BASE KIT	3804582	21368
118	ASSEMBLY,SLAVE PISTON	3753	4015690	404D 24 VDC D/L BASE KIT	3804583	21369
119	CAPSCREW,CYLINDER HEAD	3759	4015714	MODEL 411 12 VDC BASE KIT	3804584	21371
120	CROSSHEAD,EXHAUST VALVE	3763	4015712	MODEL 411 24 VDC BASE KIT	3804585	21372
121	GUIDE, T-BOLT	3768	3871316	411 24 VDC D/L BASE KIT	3804586	21373
122	SWITCH GRP	3776	3871317	MD 425A 12 VDC STAND KIT	3804587	21375
123	PLATE	3777	3871318	425A 24VDC S/L STAND KIT	3804588	21376
124	LOOM, AUTO	3778	3871319	425A 24 VDC D/L STAND KIT	3804589	21377
125	WIRE,HARNESS	3781	3871320	MD 430 12VDC STANDARD KIT	3804590	21379
126	BUTTON HEAD SCREW	3790	3871321	MODEL 440 12VDC BASE KIT	3804591	21381
127	TERMINAL,SPADE	3807	3871324	MODEL 440 24VDC BASE KIT	3804592	21382
128	COVER,CONTROL VALVE	3813	4015719	MODEL 440 12VDC BASE KIT	3804593	21383
129	HARNESS	3881	3871325	MODEL 450A VDC BASE KIT	3804594	21385
130	FLAT WASHER	3891	3871326	MODEL 450A 24 VDC BASE KT	3804595	21386
131	GAGE,FEELER	3912	3871327	450A 24VDC D/L BASE KIT	3804596	21387
132	SPRING,MASTER PISTON	3939	3871328	450B 12 VDC BASE KIT	3804597	21388
133	CONTROL,ENG BRAKE CABIN*	3965	3042594	450B 24 VDC BASE KIT	3804598	21389
134	CAB CONTROL GRP	3975	3871329	450B 24 VDC D/L BASE KIT	3804599	21390
135	MASTER PISTON	4089	3871330	455B 12 VDC BASE KIT	3804603	21395
136	COVER, CONTROL VALVE	4136	3871331	455B 24 VDC BASE KIT	3804604	21396
137	SPACER GRP, FAN BRACKET	5344	3871332	455B 24 VDC D/L BASE KIT	3804665	21397
138	SCREW,PAN HEAD	5377	3871333	MD425A 12VDC COLMT K120	3804812	22613
139	LOCK WASHER	5378	3871334	EXHAUST BRAKE KIT TMVO	3804848	22888
140	WASHER,SUPPORT	6788	3871335	EXHAUST BK GP TMVO CECO	3804849	22889
141	SPRING,INNER SLAVE PISTON	6789	3871336	EXHAUST GROUP PRE 1994 TMVO	3804854	22898
142	CAPSCREW,3/8-16 HEX HEAD	6792	3871337	PNEUMATIC GROUP	3806237	24926
143	BRACKET,THROTTLE SWITCH	6796	3871338	PNEUMATIC GROUP	3806238	24928
144	CABLE TIE	6833	3871339	BRAKE,ENGINE*	3865150	20640
145	SHIM,LAMINATED	7080	3871341	Filter, Air EXB 5.9	3870837	19480
146	SHIM,LAMINATED	7081	3871342	SWITCH, STALK	3870838	31885

#	Description	Jacobs #	Cummins #	Description	Cummins #	Jacobs #
147	WASHER,FLAT	7215	4015715	ISB-TMVO EXT BRAKE ASSY CECC	3870839	26893
148	HARNESS	7221	3871343	ISB-TMVO EXT BRAKE ASSY MOPA	3870840	28087
149	FLAT SPRING	7447	3871344	VALVE, SOLENOID	3870850	24899
150	SPRING,COMPRESSION	7500	3871345	SLEEVE, EXHAUST	3870852	18403
151	FEELER GAGE .013 INCH	7539	3871346	GASKET	3870865	25432
152	SLAVE PISTON	7623	3871347	CROSSHEAD,EXHAUST	3871200	1003
153	SWITCH ASSY (NEC GRD)	7671	3871348	SPRING,CONTROL VALVE	3871201	1012
154	SLAVE PISTON (SHORT)	7696	3871349	SCREW,RKR LEVER ADJUSTING	3871202	1015
155	RETAINER,SLAVE PISTON SPG	8895	3871350	MASTER PISTON	3871203	1017
156	NUT,HEX 1/2-20	9353	3871351	BALL	3871204	1021
157	SPRING,INNER SLAVE PISTON	9432	3871352	SPRING,SLAVE PISTON	3871205	1022
158	SPRING,OUTER SLAVE PISTON	9433	3871353	RING,RETAINING	3871206	1023
159	RETAINER,SLAVE PISTON SPG	9435	3871354	NUT,HEX JAM	3871207	1026
160	MASTER PISTON	9438	3871355	WASHER	3871208	1030
161	SLAVE PISTON	9439	3871356	SET SCREW	3871209	1031
162	RETAINING RING	9645	3871357	CAPSCREW	3871210	1033
163	SET SCREW	9916	3871359	WASHER,OIL TUBE CAPSCREW	3871212	1049
164	ENGINE CONTROL GRP	10131	3871360	CAPSCREW	3871213	1050
165	CAB CONTROL GRP	10132	3871361	SEAL RING	3871214	1051
166	SEAL,GROMMET*	10180	3251588	STUD,MOUNTING	3871215	1055
167	RETAINER, SPRING	10819	3871362	SEAL RING, UPPER	3871216	1081
168	SPRING	10843	3871363	SEAL,RECTANGULAR RING	3871218	1083
169	RETAINER,SPRING	11251	3871364	WASHER,OIL TUBE	3871219	1091
170	COVER,CONTROL VALVE	11252	3871365	NUT,HEX	3871220	1094
171	SPRING,COMPRESSION	11253	3871366	GRINDING GAGE	3871221	1153
172	SPRING,CHECK VALVE STOP	11259	3871367	BRACKET,SWITCH MOUNTING	3871222	1178
173	SPRING,CHECK VALVE SPG	11260	3871368	ARM,SWITCH ACUTATING	3871223	1179
174	RETAINING RING, CHK VALVE	11261	3871369	COVER,SWITCH	3871224	1180
175	BALL, CHECK VALVE	11262	3871370	NUT,HEX	3871225	1181
176	RESET SCREW ASSY	11267	3871371	SCREW,HEX HEAD MACHINE	3871226	1182
177	VALVE,CHECK	11283	3871372	CONTROL VALVE COVER	3871227	1189
178	RING,RETAINING	11284	3871373	SPOOL ASSY.,CONTROL VALVE	3871228	1200
179	SLAVE PISTON	11377	3871374	SPACER,AIR INTAKE	3871229	1226
180	RESET SCREW ASSY	11382	3871375	CONNECTOR,AIR OUTLET	3871230	1229
181	CROSSHEAD,EXHAUST	11392	3871376	STUD,MACHINED ASSY.	3871231	1232
182	GASKET	11393	3871377	SPACER,COMP. REL. LEVER	3871232	1235
183	NUT	11394	3871378	SPACER,FAN BRACKET	3871233	1236
184	NUT,HEX JAM 1/2-20	11395	3871379	CROSSHEAD,EXHAUST	3871234	1239
185	SPRING, CONTROL VALVE	11434	4024754	GASKET,BRAKE HOUSING	3871235	1243
186	SPACER,FINISHED	11445	3871380	SCREW,TAPPING	3871236	1244
187	DISH,OIL SUPPLY	11539	3871381	BUTTON HEAD SCREW	3871238	1265
188	PLATE,OIL SUPPLY	11540	3871382	SPACER GRP, MANIFOLD CONN	3871239	1271
189	BUTTON, HEAD SCREW	11544	3871383	AIR INTAKE MANIFOLD CONN	3871240	1273
190	FLAT WASHER 6 MM	11545	3871384	NUT	3871241	1276
191	O-RING	11553	3871385	RETAINER,SLAVE PISTON SPG	3871242	1289
192	HEX HEAD BOLT, M14X180	11556	3871386	SWITCH,ON/OFF - DASH CONT	3871243	1304
193	CONNECTOR,OIL	11557	3871387	PLATE,ON/OFF SWITCH	3871244	1305
194	SPRING	11720	3871388	EXTENSION,OIL TUBE	3871245	1422
195	GASKET	11748	3871389	SLAVE PISTON	3871246	1484

#	Description	Jacobs #	Cummins #	Description	Cummins #	Jacobs #
196	SPRING,CONTROL VALVE	11823	3871390	SLAVE PISTON (SHORT)	3871247	1486
197	FLAT SPRING	11841	3871391	CAPSCREW	3871248	1492
198	HSG ATT PARTS GRP	11898	3871596	TAB,QUICK DISCONNECT	3871249	1512
199	SPCR ATT PARTS GRP	11899	3871597	SPRING,CONTROL VLVE INNER	3871250	1518
200	SPACER, D/L 404BG	11908	3871392	SPRING,CONTROL VALVE STOP	3871251	1519
201	SPOOL ASSY.,CONT. VALVE	11930	3871393	CLAMP,SWITCH	3871252	1531
202	NUT,HEX 1/2-20	11995	3871394	DIODE	3871253	1534
203	CLUTCH SWITCH	12246	3871395	SCREW,ROUND HEAD MACHINE	3871254	1537
204	FOOT SWITCH GRP	12260	3871396	WASHER	3871255	1538
205	CLUTCH SWITCH GRP	12261	3871397	SETSCREW	3871256	1549
206	STOP,SWITCH OVER-TRAVEL	12262	3871398	SCREW,ASSEMBLY	3871257	1558
207	BRACKET,CLUTCH SWITCH	12269	3871399	LOCK WASHER	3871258	1559
208	RING, RETAINING	12291	4024755	NUT	3871259	1713
209	SCREW,HEXAGON HEAD CAP*	12292	3063550	BUTTON HEAD SCREW	3871260	1722
210	SLAVE PISTON (SHORT)	12397	3871400	GASKET	3871261	2164
211	SLAVE PISTON (SHORT)	12419	3871401	CAPSCREW,SOCKET HEAD	3871262	2375
212	855 POWER PACK	12420	3871593	CLAMP	3871263	2376
213	PISTON, ACCUMULATOR	12983	4024756	HARNESS,SOLENOID	3871264	2390
214	SPRING, ACCUMULATOR	12990	4024757	PLATE, SWITCH	3871265	2959
215	BUTT SPLICE	13078	3871402	STUD,MOUNTING	3871267	2856
216	O-RING	13155	3871404	SWITCH GRP.,TOGGLE	3871268	2957
217	SCREW,INJ RKR LEVER ADJ	13293	3871405	NUT,HOLD DOWN	3871269	3073
218	GASKET (3 PACKAGED)	13294	4025000	TUBE ASSY.,OIL SUPPLY	3871270	3077
219	AUTO-LASH KIT	13343	3871407	TEE,MALE PIPE	3871271	3079
220	AUTO-LASH ASSY	13377	3871409	FEELER GAGE .018 INCH	3871272	3087
221	RETAINER,SLAVE PISTON SPG	13500	3871410	TEE,FEMALE PIPE	3871273	3096
222	STUD & SPACER GRP	13538	3871411	MASTER PISTON	3871274	3106
223	STUD*	13540	3063548	SPRING,MASTER PISTON	3871275	3107
224	STUD*	13542	3063547	SPRING,CONTROL VALVE	3871276	3109
225	STUD & SPACER GRP	13576	3871412	STUD,ROCKER COVER	3871277	3114
226	STUD & SPACER GRP	13578	3871413	STUD,MOUNTING	3871278	3122
227	GASKET SET	13758	3871415	WASHER,CYLINDER HEAD STUD	3871279	3127
228	STUD & SPACER GRP	13894	3871416	SEAL,RING	3871280	3130
229	GASKET SET	13898	3871417	TUBE ASSY., OIL SUPPLY	3871281	3216
230	TUNE-UP KIT	13950	3871418	SPACER,FAN BRACKET	3871283	3251
231	O-RING	14026	3871419	SHAFT,COMPRESSIN RELIEF	3871284	3254
232	LEVER,SWITCH ACTUATING	14027	3871420	RECEPTACLE,QUICK DISCONN	3871285	3278
233	T-BOLT	14028	3871421	NUT,HEX #6-32	3871287	3306
234	NUT, T-BOLT	14030	3871422	MASTER PISTON	3871288	3327
235	ENGINE CONTROL GRP	14035	3871423	SPRING,MASTER PISTON	3871289	3328
236	STUD & SPACER GRP	14040	3871424	MASTER PISTON	3871290	3329
237	ENGINE CONTROL GRP	14068	3871425	POSITIONER,VALVE SPRING	3871291	3402
238	ENGINE CONTROL	14070	3871426	SPRING,CONTROL VALVE	3871294	3410
239	HARNESS GRP	14196	3871427	PLATE, DASH SWITCH	3871302	3585
240	FEELER GAGE .015 INCH	14341	3871428	SWITCH	3871303	3586
241	SCREW & PIN ASSY	14407	3871429	SWITCH GRP	3871304	3590
242	SWITCH GRP	14468	3871430	SWITCH,HYDRAULIC	3871305	3591
243	MASTER PISTON	14489	3871431	SHELL	3871306	3592
244	PLUG,STRAIGHT O-RING	14506	3871432	SLEEVE	3871307	3593

#	Description	Jacobs #	Cummins #	Description	Cummins #	Jacobs #
245	ADAPTER,SAE O-RING	14542	3871433	TERMINAL	3871308	3594
246	HOSE ASSY	14545	3871434	SCREW,INJ RKR LEVER ADJ	3871310	3678
247	FEELER GAGE .021 INCH	14547	3871435	TUBE,SHRINK	3871311	3707
248	NUT, CAP	14565	3871436	TUBE,SHRINK	3871312	3708
249	S.T.C. INTERFACE	14582	3871437	NUT, HEX JAM 3/8-24	3871313	3720
250	HARNES, SOLENOID 10 INCH	14619	3871438	SET SCREW	3871314	3748
251	ADAPTER,1/2-20 X 9/16-18	14807	3871439	CAPSCREW	3871315	3749
252	OIL SUPPLY ATTACH PTS GRP	14809	3871440	GUIDE, T-BOLT	3871316	3768
253	GASKET (3 PACKAGED)	14848	4025002	SWITCH GRP	3871317	3776
254	RETAINER,SLAVE PISTON GRP	14849	3871441	PLATE	3871318	3777
255	SLAVE PISTON	14864	3871442	LOOM, AUTO	3871319	3778
256	SPRING,SLAVE PISTON	14867	3871443	WIRE,HARNES	3871320	3781
257	CLAMP,HARNES	14908	4015718	BUTTON HEAD SCREW	3871321	3790
258	SCREW,OIL SUPPLY	14927	3871444	TERMINAL,SPADE	3871324	3807
259	COVER,CONTROL VALVE	14928	3871445	HARNES	3871325	3881
260	RETAINING RING	15561	3871446	FLAT WASHER	3871326	3891
261	STUD & SPACER GRP	15623	3871447	GAGE,FEELER	3871327	3912
262	STUD	15633	3063529	SPRING,MASTER PISTON	3871328	3939
263	STUD	15635	3063530	CAB CONTROL GRP	3871329	3975
264	STUD	15637	3063531	MASTER PISTON	3871330	4089
265	LOW ENG SPEED CUTOFF GRP	15644	3871448	COVER, CONTROL VALVE	3871331	4136
266	CONTROL MODULE	15645	3871449	SPACER GRP, FAN BRACKET	3871332	5344
267	WIRE	15758	3871683	SCREW,PAN HEAD	3871333	5377
268	WIRE	15759	3871684	LOCK WASHER	3871334	5378
269	HARNES ASSY	15802	3871450	WASHER,SUPPORT	3871335	6788
270	SCREW,HEXAGON HEAD CAP ***	15829	3871612	SPRING,INNER SLAVE PISTON	3871336	6789
271	FEELER GAGE .030 INCH	15877	3871451	CAPSCREW,3/8-16 HEX HEAD	3871337	6792
272	FEELER GAGE .037 INCH	15878	3871452	BRACKET,THROTTLE SWITCH	3871338	6796
273	NUT,REGULAR HEXAGON*	15901	3063532	CABLE TIE	3871339	6833
274	TAG,INSTRUCTION*	15908	3063571	SHIM,LAMINATED	3871341	7080
275	TAB,SLEEVE LASH .030 INCH	15909	3871453	SHIM,LAMINATED	3871342	7081
276	TAB,SLEEVE LASH .037 INCH	15910	3871454	HARNES	3871343	7221
277	TAB SET,SLAVE LASH	15930	3871631	FLAT SPRING	3871344	7447
278	BRAKE,ENGINE	16007	3065137	SPRING,COMPRESSION	3871345	7500
279	HOUSING ASSY., 430 24 VDC	16009	3871455	FEELER GAGE .013 INCH	3871346	7539
280	HARNES,OUTPUT LESRCO	16175	3871457	SLAVE PISTON	3871347	7623
281	HARNES,INPUT LESRCO	16177	3871458	SWITCH ASSY (NEC GRD)	3871348	7671
282	SWITCH,ON/OFF	16264	3871459	SLAVE PISTON (SHORT)	3871349	7696
283	SWITCH,3 POSITION	16265	3871460	RETAINER,SLAVE PISTON SPG	3871350	8895
284	SWITCH,TOGGLE	16266	3871461	NUT,HEX 1/2-20	3871351	9353
285	NT PACE CONTROL GROUP	16327	3871462	SPRING,INNER SLAVE PISTON	3871352	9432
286	SOL ASSY,12 VDC S/L BLADE	16440	3871463	SPRING,OUTER SLAVE PISTON	3871353	9433
287	SOL ASSY,24 VDC S/L BLADE	16441	3871464	RETAINER,SLAVE PISTON SPG	3871354	9435
288	SOL ASSY,24 VDC D/L BLADE	16442	3871465	MASTER PISTON	3871355	9438
289	RECEPTACLE	16467	3871466	SLAVE PISTON	3871356	9439
290	FEELER GAGE .024 INCH	16560	3871467	RETAINING RING	3871357	9645
291	SCREW,HEXAGON HEAD SET*	16627	3072887	SET SCREW	3871359	9916
292	BRAKE,ENGINE*	16656	3069111	ENGINE CONTROL GRP	3871360	10131
293	HSG ASSY 425A 24 VDC S/L	16660	3871468	CAB CONTROL GRP	3871361	10132

#	Description	Jacobs #	Cummins #	Description	Cummins #	Jacobs #
294	HSG ASSY 425A VDC D/L	16667	3871469	RETAINER, SPRING	3871362	10819
295	FEELER GAGE .046 INCH	16683	3871470	SPRING	3871363	10843
296	FEELER GAGE .040 INCH	16704	3871471	RETAINER,SPRING	3871364	11251
297	GASKET	16723	3871472	COVER,CONTROL VALVE	3871365	11252
298	NUT,HEX 3/8-24	16766	3871474	SPRING,COMPRESSION	3871366	11253
299	MASTER PISTON	16772	3871475	SPRING,CHECK VALVE STOP	3871367	11259
300	MASTER PISTON	16773	3871476	SPRING,CHECK VALVE SPG	3871368	11260
301	SLAVE PISTON	16774	3871477	RETAINING RING, CHK VALVE	3871369	11261
302	FLAT SPRING	16810	3871478	BALL, CHECK VALVE	3871370	11262
303	SPRING,INNER SLAVE PISTON	16844	3871479	RESET SCREW ASSY	3871371	11267
304	SPRING,OUTER SLAVE PISTON	16845	3871480	VALVE,CHECK	3871372	11283
305	CLAMP,HOSE	16869	3871482	RING,RETAINING	3871373	11284
306	ADAPTER,90 DEGREE ELBOW	16894	3871483	SLAVE PISTON	3871374	11377
307	RESET SCREW ASSY	16914	3871484	RESET SCREW ASSY	3871375	11382
308	SPACER ATTACHING PART GRP	16927	3871485	CROSSHEAD,EXHAUST	3871376	11392
309	MECHANICAL RELAY	16933	3871486	GASKET	3871377	11393
310	HOSE ASSY, OIL SUPPLY	16955	3871487	NUT	3871378	11394
311	HOSE ASSY,OIL SUPPLY (INT	16960	3871488	NUT,HEX JAM 1/2-20	3871379	11395
312	HOSE ASSY,OIL SUPPLY	16961	3871489	SPACER,FINISHED	3871380	11445
313	SEAL	16963	3871685	DISH,OIL SUPPLY	3871381	11539
314	TOOL,CONT VALVE REMOVAL	16978	3871490	PLATE,OIL SUPPLY	3871382	11540
315	BULKHEAD ADAPTER	16980	3871491	BUTTON, HEAD SCREW	3871383	11544
316	HSG ATT PARTS GRP	16989	3871602	FLAT WASHER 6 MM	3871384	11545
317	CONTROL,ENG BRAKE CABIN*	17002	3883216	O-RING	3871385	11553
318	MASTER PISTON	17036	3871492	HEX HEAD BOLT, M14X180	3871386	11556
319	CONTROL,ENG BRAKE ENGINE*	17075	3883743	CONNECTOR,OIL	3871387	11557
320	MASTER PISTON	17124	3871493	SPRING	3871388	11720
321	HEX JAM NUT	17134	3871665	GASKET	3871389	11748
322	SCREW	17152	3871494	SPRING,CONTROL VALVE	3871390	11823
323	COVER,SWITCH	17153	3871495	FLAT SPRING	3871391	11841
324	CLAMP,SUPPORT	17180	3871496	SPACER, D/L 404BG	3871392	11908
325	WASHER,SEALING	17184	3073977	SPOOL ASSY.,CONT. VALVE	3871393	11930
326	ADAPTER,90 DEGREE ELBOW	17185	3871497	NUT,HEX 1/2-20	3871394	11995
327	UNION,MALE*	17186	3073976	CLUTCH SWITCH	3871395	12246
328	SWITCH, HI/LOW	17192	3871498	FOOT SWITCH GRP	3871396	12260
329	PLATE,SWITCH	17193	3871499	CLUTCH SWITCH GRP	3871397	12261
330	SWITCH GRP,ON/OFF	17195	3871501	STOP,SWITCH OVER-TRAVEL	3871398	12262
331	LEVER, SWITCH	17247	3871502	BRACKET,CLUTCH SWITCH	3871399	12269
332	CLAMP,LEVER	17248	3871503	SLAVE PISTON (SHORT)	3871400	12397
333	HARNES,CELECT	17256	3871504	SLAVE PISTON (SHORT)	3871401	12419
334	SLAVE PISTON - SHORT	17260	3871505	BUTT SPLICE	3871402	13078
335	HARNES,IN-LINE SWITCH	17263	3871506	O-RING	3871404	13155
336	BRAKE,ENGINE	17285	3079659	SCREW,INJ RKR LEVER ADJ	3871405	13293
337	BRAKE,ENGINE	17287	3079660	AUTO-LASH KIT	3871407	13343
338	FRT HSG ASSY 404BG/D 12V	17289	3871627	AUTO-LASH ASSY	3871409	13377
339	RR HSG ASSY 404BG/D 12V	17291	3871628	RETAINER,SLAVE PISTON SPG	3871410	13500
340	FRT HSG ASSY 404BG/D 12V	17293	3871629	STUD & SPACER GRP	3871411	13538
341	RR HSG ASSY 404BG/D 12V	17295	3871630	STUD & SPACER GRP	3871412	13576
342	CROSSHEAD ASSEMBLY	17302	3073952	STUD & SPACER GRP	3871413	13578

#	Description	Jacobs #	Cummins #	Description	Cummins #	Jacobs #
343	BRAKE,ENGINE	17311	3883779	GASKET SET	3871415	13758
344	SWITCH GRP, 3 MODE	17328	3871511	STUD & SPACER GRP	3871416	13894
345	SWITCH GRP, 2 MODE	17346	3871512	GASKET SET	3871417	13898
346	UPGRADE KIT,404B TO 404BG	17351	3871513	TUNE-UP KIT	3871418	13950
347	TUBE, LUBE OIL SUPPLY*	17352	3073975	O-RING	3871419	14026
348	WIRING HARNESS	17364	3871686	LEVER,SWITCH ACTUATING	3871420	14027
349	CONNECTOR,ELECTRICAL*	17366	3073972	T-BOLT	3871421	14028
350	CONNECTOR,ELECTRICAL*	17367	3073974	NUT, T-BOLT	3871422	14030
351	HARNESS,WIRING	17368	3892599	ENGINE CONTROL GRP	3871423	14035
352	HARNESS,WIRING	17389	3892598	STUD & SPACER GRP	3871424	14040
353	MASTER PISTON	17396	3871515	ENGINE CONTROL GRP	3871425	14068
354	TERMINAL,SPADE	17400	4015710	ENGINE CONTROL	3871426	14070
355	MASTER PISTON	17408	3871516	HARNESS GRP	3871427	14196
356	SLAVE PISTON	17409	3871517	FEELER GAGE .015 INCH	3871428	14341
357	FLAT SPRING	17412	3871518	SCREW & PIN ASSY	3871429	14407
358	HARNESS,WIRING	17416	3065171	SWITCH GRP	3871430	14468
359	BRAKE,ENGINE	17421	3073771	MASTER PISTON	3871431	14489
360	BRAKE,ENGINE	17423	3073772	PLUG,STRAIGHT O-RING	3871432	14506
361	BRAKE,ENGINE	17425	3871519	ADAPTER,SAE O-RING	3871433	14542
362	BRAKE,ENGINE	17427	3871520	HOSE ASSY	3871434	14545
363	HSG,404D FRT 24 VDC D/L	17429	3871521	FEELER GAGE .021 INCH	3871435	14547
364	HSG,404D REAR 24 VDC D/L	17431	3871522	NUT, CAP	3871436	14565
365	TOOL BOX	17471	3871524	S.T.C. INTERFACE	3871437	14582
366	ENGINE CONTROL GRP	17491	3871525	HARNESS, SOLENOID 10 INCH	3871438	14619
367	CONTROL,ENG BRAKE CABIN*	17492	3883602	ADAPTER,1/2-20 X 9/16-18	3871439	14807
368	BRAKE,ENGINE	17493	3892017	OIL SUPPLY ATTACH PTS GRP	3871440	14809
369	BRAKE,ENGINE	17494	3892016	RETAINER,SLAVE PISTON GRP	3871441	14849
370	CONTROL,ENG BRAKE ENGINE*	17503	3892018	SLAVE PISTON	3871442	14864
371	HARNESS	17504	3871687	SPRING,SLAVE PISTON	3871443	14867
372	RETAINING RING	17507	3871526	SCREW,OIL SUPPLY	3871444	14927
373	SWITCH ASSY	17533	3871688	COVER,CONTROL VALVE	3871445	14928
374	BRACKET,SWITCH	17571	3871527	RETAINING RING	3871446	15561
375	SCREW & WASHER ASSY.	17573	3871528	STUD & SPACER GRP	3871447	15623
376	SWITCH ASSY, MOUNTED	17574	3871529	LOW ENG SPEED CUTOFF GRP	3871448	15644
377	RELAY BASE	17593	3871689	CONTROL MODULE	3871449	15645
378	TERMINAL ASSY.	17657	3871530	HARNESS ASSY	3871450	15802
379	ENGINE CONTROL GROUP	17660	3871531	FEELER GAGE .030 INCH	3871451	15877
380	GROUND WIRE-DUAL LEAD	17661	3871532	FEELER GAGE .037 INCH	3871452	15878
381	BRACKET,OIL SUPPLY	17665	3871533	TAB,SLEEVE LASH .030 INCH	3871453	15909
382	FEELER GAGE .023 INCH	17685	3871534	TAB,SLEEVE LASH .037 INCH	3871454	15910
383	SWITCH BRACKET	17686	3871690	HOUSING ASSY., 430 24 VDC	3871455	16009
384	TUNE-UP KIT (401A,B,C)	17687	3871535	HARNESS,OUTPUT LESRCO	3871457	16175
385	TUNE-UP KIT (420 & 425)	17688	3871536	HARNESS,INPUT LESRCO	3871458	16177
386	TUNE-UP KIT (425A)	17689	3871537	SWITCH,ON/OFF	3871459	16264
387	TUNE-UP KIT (430)	17690	3871538	SWITCH,3 POSITION	3871460	16265
388	RETAINER,SLAVE PISTON	17721	3871539	SWITCH,TOGGLE	3871461	16266
389	TUNE-UP KIT (404 & 404B)	17723	3871540	NT PACE CONTROL GROUP	3871462	16327
390	ENGINE CONTROL GRP	17737	3871542	SOL ASSY,12 VDC S/L BLADE	3871463	16440
391	CAB CONTROL GRP	17738	3871543	SOL ASSY,24 VDC S/L BLADE	3871464	16441

#	Description	Jacobs #	Cummins #	Description	Cummins #	Jacobs #
392	SCREW,CAPTIVE WASHER CAP	17958	3074534	SOL ASSY,24 VDC D/L BLADE	3871465	16442
393	MASTER PISTON	18025	3871544	RECEPTACLE	3871466	16467
394	HARNESS,WIRING	18055	3071205	FEELER GAGE .024 INCH	3871467	16560
395	HARNESS	18103	3871691	HSG ASSY 425A 24 VDC S/L	3871468	16660
396	ADAPTER,BULLET TO SPADE	18105	3871545	HSG ASSY 425A VDC D/L	3871469	16667
397	SLAVE PISTON	18156	3871660	FEELER GAGE .046 INCH	3871470	16683
398	SLAVE PISTON SPRING-OUTER	18183	3871546	FEELER GAGE .040 INCH	3871471	16704
399	SLAVE PISTON SPRING-INNER	18184	3871547	GASKET	3871472	16723
400	ENG TO SEL SWITCH HARNESS	18187	3871548	NUT,HEX 3/8-24	3871474	16766
401	SWITCH	18188	3871549	MASTER PISTON	3871475	16772
402	SLAVE PISTON SPG RETAINER	18197	3871550	MASTER PISTON	3871476	16773
403	SWITCH,RELAY	18199	4024724	SLAVE PISTON	3871477	16774
404	SPRING, SLAVE PISTON	18209	4024749	FLAT SPRING	3871478	16810
405	SLAVE PISTON REMOVAL TOOL	18238	3871654	SPRING,INNER SLAVE PISTON	3871479	16844
406	ENGINE CONTROL GROUP	18250	3871692	SPRING,OUTER SLAVE PISTON	3871480	16845
407	RELAY	18257	3929069	CLAMP,HOSE	3871482	16869
408	BRAKE,ENGINE	18267	3254989	ADAPTER,90 DEGREE ELBOW	3871483	16894
409	BODY,CONT VLV PRESS TEST	18282	3871552	RESET SCREW ASSY	3871484	16914
410	ADAPTER,PRESSURE TEST	18283	3871553	SPACER ATTACHING PART GRP	3871485	16927
411	BODY,SOL PRESSURE TEST	18284	3871554	MECHANICAL RELAY	3871486	16933
412	PRESSURE GAGE	18285	3871555	HOSE ASSY, OIL SUPPLY	3871487	16955
413	TAB SET,SLAVE LASH	18314	3871556	HOSE ASSY,OIL SUPPLY (INT	3871488	16960
414	RELAY	18352	3871693	HOSE ASSY,OIL SUPPLY	3871489	16961
415	CYLINDER,AIR	18395	3929077	TOOL,CONT VALVE REMOVAL	3871490	16978
416	CLAMP,V BAND	18400	3929060	BULKHEAD ADAPTER	3871491	16980
417	SLEEVE, EXHAUST	18403	3870852	MASTER PISTON	3871492	17036
418	SWITCH ASSY, NEG GROUND	18471	3871694	MASTER PISTON	3871493	17124
419	TOOL BOX W/FOAM INSERT	18479	3871557	SCREW	3871494	17152
420	PLUG,PIPE	18485	3871558	COVER,SWITCH	3871495	17153
421	SCREW,HEXAGON HEAD CAP	18511	3893940	CLAMP,SUPPORT	3871496	17180
422	STUD,MOUNTING	18541	4015711	ADAPTER,90 DEGREE ELBOW	3871497	17185
423	HARNESS,MAIN	18542	4015692	SWITCH, HI/LOW	3871498	17192
424	HARNESS,ENGINE	18543	4015693	PLATE,SWITCH	3871499	17193
425	SENSOR,SPEED	18544	4015694	SWITCH GRP,ON/OFF	3871501	17195
426	HARNESS,POWER	18546	4015696	LEVER, SWITCH	3871502	17247
427	HARNESS,OUTPUT/BRAKE	18548	4015698	CLAMP,LEVER	3871503	17248
428	GROUP,MOUNTING BRACKET	18563	4015699	HARNESS,CELECT	3871504	17256
429	CONTROL GROUP 24 VDC	18610	3871695	SLAVE PISTON - SHORT	3871505	17260
430	SWITCH-FUEL PUMP WIRED	18634	3871559	HARNESS,IN-LINE SWITCH	3871506	17263
431	STRAIGHT ADAPTER	18685	3871560	SWITCH GRP, 3 MODE	3871511	17328
432	HARNESS,WIRING	18687	3080422	SWITCH GRP, 2 MODE	3871512	17346
433	SPRING, FLAT	18722	4024751	UPGRADE KIT,404B TO 404BG	3871513	17351
434	SCREW, HEX HEAD CAP	18730	4024753	MASTER PISTON	3871515	17396
435	FLAT SPRING	18792	3871561	MASTER PISTON	3871516	17408
436	GASKET, EXH OUT CONN	18892	3929057	SLAVE PISTON	3871517	17409
437	VALVE,CHECK	18908	3929050	FLAT SPRING	3871518	17412
438	SCREW,HEXAGON HEAD SET*	18929	3080759	BRAKE,ENGINE	3871519	17425
439	ADAPTER O-RING	18931	3871667	BRAKE,ENGINE	3871520	17427
440	HSG REPLACE GRP 25B-400H	19039	3871563	HSG,404D FRT 24 VDC D/L	3871521	17429

#	Description	Jacobs #	Cummins #	Description	Cummins #	Jacobs #
441	GASKET, EXH OUT CONN	19047	3929058	HSG,404D REAR 24 VDC D/L	3871522	17431
442	SPACER,ROCKER LEVER COVER*	19064	3084583	TOOL BOX	3871524	17471
443	SLAVE PISTON	19103	3871642	ENGINE CONTROL GRP	3871525	17491
444	OUTER SLAVE PISTON SPRING	19104	3871643	RETAINING RING	3871526	17507
445	INNER SLAVE PISTON SPRING	19105	3871644	BRACKET,SWITCH	3871527	17571
446	RETAINER, SLAVE PISTON SPRING	19139	4024504	SCREW & WASHER ASSY.	3871528	17573
447	RETAINER, SLAVE PISTON SPRING	19139	4025404	SWITCH ASSY, MOUNTED	3871529	17574
448	EXB59 EXHAUST BRAKE ASSY	19207	3928757	TERMINAL ASSY.	3871530	17657
449	EXHAUST ASSY EXC83/EXISC	19229	3928758	ENGINE CONTROL GROUP	3871531	17660
450	RESERVOIR	19230	3929062	GROUND WIRE-DUAL LEAD	3871532	17661
451	PRESSURE SWITCH-CEEMAT	19240	3871566	BRACKET,OIL SUPPLY	3871533	17665
452	MASTER PISTON	19255	3871659	FEELER GAGE .023 INCH	3871534	17685
453	MODIFICATION KIT CEEMAT X	19260	3871567	TUNE-UP KIT (401A,B,C)	3871535	17687
454	VALVE,SOLENOID	19304	3929051	TUNE-UP KIT (420 & 425)	3871536	17688
455	TUNE-UP KIT 440A & 450A/B	19305	3871568	TUNE-UP KIT (425A)	3871537	17689
456	BRAKE,ENGINE	19396	3084581	TUNE-UP KIT (430)	3871538	17690
457	BRAKE,ENGINE	19397	3084582	RETAINER,SLAVE PISTON	3871539	17721
458	ON/OFF SWITCH	19408	3871648	TUNE-UP KIT (404 & 404B)	3871540	17723
459	HARNESS ASSY-CEEMAT	19412	3871575	ENGINE CONTROL GRP	3871542	17737
460	KIT, ENGINE CONTROL	19429	3803911	CAB CONTROL GRP	3871543	17738
461	KIT,BRAKE SWITCH	19432	3803906	MASTER PISTON	3871544	18025
462	BRACKET,PUMP	19439	3929055	ADAPTER,BULLET TO SPADE	3871545	18105
463	BRACKET,PUMP	19440	3929056	SLAVE PISTON SPRING-OUTER	3871546	18183
464	Filter, Air ESB 5.9	19480	3870837	SLAVE PISTON SPRING-INNER	3871547	18184
465	DRAINCOCK	19484	3929064	ENG TO SEL SWITCH HARNESS	3871548	18187
466	VALVE,PRESSURE RELIEF	19485	3929065	SWITCH	3871549	18188
467	VALVE,CHECK	19486	3929066	SLAVE PISTON SPG RETAINER	3871550	18197
468	HARNESS (GROUND)	19572	3871696	BODY,CONT VLV PRESS TEST	3871552	18282
469	SWITCH,PRESSURE	19588	3929067	ADAPTER,PRESSURE TEST	3871553	18283
470	GASKET,EXH OUT CONNECTION	19590	3929070	BODY,SOL PRESSURE TEST	3871554	18284
471	GASKET,EXH OUT CONNECTION	19594	3929071	PRESSURE GAGE	3871555	18285
472	CLAMP,V BAND	19595	3929073	TAB SET,SLAVE LASH	3871556	18314
473	SET,EXHAUST BRAKE	19599	3803914	TOOL BOX W/FOAM INSERT	3871557	18479
474	HARNESS,WIRING	19645	3929068	PLUG,PIPE	3871558	18485
475	HSG ASSY 440 24 VDC D/L	19683	3871577	SWITCH-FUEL PUMP WIRED	3871559	18634
476	HSG ASSY 440A 12 VDC S/L	19692	3871578	STRAIGHT ADAPTER	3871560	18685
477	CROSSHEAD,VALVE*	19805	3071207	FLAT SPRING	3871561	18792
478	CROSSHEAD,VALVE	19807	3071208	HSG REPLACE GRP 25B-400H	3871563	19039
479	TUNE-UP KIT MOD 404D 411	19848	3871580	HSG ASSY 450B 12 VDC PKGD	3871565	21457
480	GAGE-FEELER .30 INCH	19954	3871585	PRESSURE SWITCH-CEEMAT	3871566	19240
481	EXTARDER KIT MOD EXB59	19961	3802671	MODIFICATION KIT CEEMAT X	3871567	19260
482	EXHAUST BRAKE KIT EXC83	19963	3802672	TUNE-UP KIT 440A & 450A/B	3871568	19305
483	HEX NUT	19987	3871641	HARNESS ASSY-CEEMAT	3871575	19412
484	SLEEVE	20088	3929072	HSG ASSY 440 24 VDC D/L	3871577	19683
485	SLEEVE	20089	3929059	HSG ASSY 440A 12 VDC S/L	3871578	19692
486	TUNE-UP KIT MOD 404BG	20131	3871586	TUNE-UP KIT MOD 404D 411	3871580	19848
487	EXTARDER GROUP MOD EXB59	20197	3803905	HSG 450A 24 VDC S/L PKGD	3871581	21453
488	EXTARDER GROUP MOD EXC83	20200	3803913	HSG 450A 24 VDC D/L PKGD	3871582	21455
489	AUTO-LASH 440A	20205	3871674	HSG 450B 24 VDC S/L PKGD	3871583	21459

#	Description	Jacobs #	Cummins #	Description	Cummins #	Jacobs #
490	SOLENOID SCREEN	20227	3871656	HSG 450B 24 VDC D/L PKGD	3871584	21461
491	SOLENOID SCREEN RETAINER	20228	3871655	GAGE-FEELER .30 INCH	3871585	19954
492	SEAL,RECTANGULAR RING	20229	3871638	TUNE-UP KIT MOD 404BG	3871586	20131
493	BRAKE,ENGINE	20256	3418356	CUMMINS DISTRIBUTION KIT	3871592	20744
494	HARNESS,WIRING	20364	3095433	855 POWER PACK	3871593	12420
495	KIT, BRAKE SWITCH	20395	3803908	TOGGEL SWITCH GROUP	3871594	2970
496	AUTO-LASH 450A	20449	3871675	HSG ATT PARTS GRP	3871596	11898
497	AUTO-LASH 425A, 440	20509	3871676	SPCR ATT PARTS GRP	3871597	11899
498	AUTO-LASH 430, 450A	20511	3871677	HSG ATT PARTS GRP	3871602	16989
499	VALVE,SOLENOID	20578	3284523	SCREW,HEXAGON HEAD CAP ***	3871612	15829
500	BRAKE,ENGINE*	20640	3865150	HSG ASSY	3871622	20870
501	CUMMINS DISTRIBUTION KIT	20744	3871592	HSG ASSY	3871623	21401
502	JOINT,BALL	20748	3929075	HSG ASSY	3871624	20767
503	CLIP	20750	3929076	FRT HSG ASSY 404BG/D 12V	3871627	17289
504	HSG ASSY	20767	3871624	RR HSG ASSY 404BG/D 12V	3871628	17291
505	BRACKET,AIR CYLINDER	20787	3929078	FRT HSG ASSY 404BG/D 12V	3871629	17293
506	HARNESS	20800	3871652	RR HSG ASSY 404BG/D 12V	3871630	17295
507	CAB CONTROL GROUP*	20853	3871647	TAB SET,SLAVE LASH	3871631	15930
508	WIRING DIAGRAM	20861	3871650	HARNESS,WIRING	3871634	21296
509	GROUND WIRE, D/L	20868	3871653	SEAL,RECTANGULAR RING	3871638	20229
510	HSG ASSY	20870	3871622	HEX NUT	3871641	19987
511	KIT,AIR CONTROL	20904	3803910	SLAVE PISTON	3871642	19103
512	CLAMP	20909	3871666	OUTER SLAVE PISTON SPRING	3871643	19104
513	CLIP	20910	3406919	INNER SLAVE PISTON SPRING	3871644	19105
514	KIT, TUNEUP 455 A/B/C	20923	3871704	CAB CONTROL GROUP*	3871647	20853
515	ENGINE CONTROL GROUP	20957	3871651	ON/OFF SWITCH	3871648	19408
516	SOLENOID	20997	4026538	WIRING DIAGRAM	3871650	20861
517	WASHER, PLAIN	21038	4024752	ENGINE CONTROL GROUP	3871651	20957
518	HARNESS,WIRING	21296	3871634	HARNESS	3871652	20800
519	CONTROL,ENG BRAKE CABIN*	21300	3871669	GROUND WIRE, D/L	3871653	20868
520	REAR HOUSING ASSY.	21312	3871679	SLAVE PISTON REMOVAL TOOL	3871654	18238
521	404BG 12VDC STANDARD KIT	21360	3804575	SOLENOID SCREEN RETAINER	3871655	20228
522	404BG 24 VDC S/L BASE KIT	21361	3804576	SOLENOID SCREEN	3871656	20227
523	404BG VDC D/L STANDRD KIT	21362	3804577	MASTER PISTON	3871659	19255
524	404BG/D 12VDC SPECIAL KIT	21363	3804578	SLAVE PISTON	3871660	18156
525	404BG/D VDC S/L SPEC. KIT	21364	3804579	CAB CONTROL GROUP	3871661	21479
526	404BG/D 24VDC D/L SPEC KT	21365	3804580	HEX JAM NUT	3871665	17134
527	404D 12 VDC BASE KIT	21367	3804581	CLAMP	3871666	20909
528	404D 24VDC S/L BASE KIT	21368	3804582	ADAPTER O-RING	3871667	18931
529	404D 24 VDC D/L BASE KIT	21369	3804583	CONTROL,ENG BRAKE CABIN*	3871669	21300
530	MODEL 411 12 VDC BASE KIT	21371	3804584	SWITCH, HI/LO	3871670	21441
531	MODEL 411 24 VDC BASE KIT	21372	3804585	AUTO-LASH 440A	3871674	20205
532	411 24 VDC D/L BASE KIT	21373	3804586	AUTO-LASH 450A	3871675	20449
533	MD 425A 12 VDC STAND KIT	21375	3804587	AUTO-LASH 425A, 440	3871676	20509
534	425A 24VDC S/L STAND KIT	21376	3804588	AUTO-LASH 430, 450A	3871677	20511
535	425A 24 VDC D/L STAND KIT	21377	3804589	REAR HOUSING ASSY.	3871679	21312
536	MD 430 12VDC STANDARD KIT	21379	3804590	RECEPTACLE	3871680	1955
537	MODEL 440 12VDC BASE KIT	21381	3804591	RECEPTACLE	3871681	2014
538	MODEL 440 24VDC BASE KIT	21382	3804592	SEAL RING	3871682	2236

#	Description	Jacobs #	Cummins #	Description	Cummins #	Jacobs #
539	MODEL 440 12VDC BASE KIT	21383	3804593	WIRE	3871683	15758
540	MODEL 450A VDC BASE KIT	21385	3804594	WIRE	3871684	15759
541	MODEL 450A 24 VDC BASE KT	21386	3804595	SEAL	3871685	16963
542	450A 24VDC D/L BASE KIT	21387	3804596	WIRING HARNESS	3871686	17364
543	450B 12 VDC BASE KIT	21388	3804597	HARNESS	3871687	17504
544	450B 24 VDC BASE KIT	21389	3804598	SWITCH ASSY	3871688	17533
545	450B 24 VDC D/L BASE KIT	21390	3804599	RELAY BASE	3871689	17593
546	455B 12 VDC BASE KIT	21395	3804603	SWITCH BRACKET	3871690	17686
547	455B 24 VDC BASE KIT	21396	3804604	HARNESS	3871691	18103
548	455B 24 VDC D/L BASE KIT	21397	3804665	ENGINE CONTROL GROUP	3871692	18250
549	HSG ASSY	21401	3871623	RELAY	3871693	18352
550	SWITCH, HI/LO	21441	3871670	SWITCH ASSY, NEG GROUND	3871694	18471
551	HSG 450A 24 VDC S/L PKGD	21453	3871581	CONTROL GROUP 24 VDC	3871695	18610
552	HSG 450A 24 VDC D/L PKGD	21455	3871582	HARNESS (GROUND)	3871696	19572
553	HSG ASSY 450B 12 VDC PKGD	21457	3871565	455B ROBO-LASH	3871699	21888
554	HSG 450B 24 VDC S/L PKGD	21459	3871583	AUTO-LASH ASSY	3871703	22576
555	HSG 450B 24 VDC D/L PKGD	21461	3871584	KIT, TUNEUP 455 A/B/C	3871704	20923
556	BRAKE,ENGINE*	21464	3166392	SOLENOID VALVE-12V S/L	3871707	24613
557	CAB CONTROL GROUP	21479	3871661	SOLENOID VALVE-24V S/L	3871708	24616
558	EXTARDER KIT MOD EXB59	21780	3802816	SOLENOID VALVE-24V D/L	3871709	24617
559	455B ROBO-LASH	21888	3871699	SOLENOID VALVE-12V D/L	3871711	24610
560	NUT,REGULAR HEXAGON JAM	22061	3679921	CONTROL,ENG BRAKE CABIN*	3883216	17002
561	EXHAUST BRAKE TMVO CECO	22453	3933128	CONTROL,ENG BRAKE CABIN*	3883602	17492
562	WIRE HARNESS, TMVO	22455	3933134	CONTROL,ENG BRAKE ENGINE*	3883743	17075
563	RELAY	22456	3933135	BRAKE,ENGINE	3883779	17311
564	FUEL PUMP SWITCH ASSEMBLY	22522	3933129	BRAKE,ENGINE	3892016	17494
565	AUTO-LASH ASSY	22576	3871703	BRAKE,ENGINE	3892017	17493
566	BRAKE,ENGINE*	22600	3166308	CONTROL,ENG BRAKE ENGINE*	3892018	17503
567	MD425A 12VDC COLMT K120	22613	3804812	HARNESS,WIRING	3892598	17389
568	CONTROL,ENG BRAKE ENGINE*	22677	3255197	HARNESS,WIRING	3892599	17368
569	SPACER,ROCKER LEVER COVER*	22687	3406906	SCREW,HEXAGON HEAD CAP	3893940	18511
570	KIT,ENGINE BRAKE	22695	3800765	EXB59 EXHAUST BRAKE ASSY	3928757	19207
571	EXHAUST PIPE PRE-94	22763	3933136	EXHAUST ASSY EXC83/EXISC	3928758	19229
572	VACUUM SOLENOID ASSEMBLY	22875	3933133	VALVE,CHECK	3929050	18908
573	VACUUM PRESSURE SWITCH ASS	22876	3933132	VALVE,SOLENOID	3929051	19304
574	EXHAUST BRAKE KIT TMVO	22888	3804848	BRACKET,PUMP	3929055	19439
575	EXHAUST BK GP TMVO CECO	22889	3804849	BRACKET,PUMP	3929056	19440
576	EXHAUST GROUP PRE 1994 TMVO	22898	3804854	GASKET, EXH OUT CONN	3929057	18892
577	BRAKE,ENGINE*	24016	3255154	GASKET, EXH OUT CONN	3929058	19047
578	SPRING, TENSION	24019	3933131	SLEEVE	3929059	20089
579	SPRING, TENSION	24020	3933130	CLAMP,V BAND	3929060	18400
580	EXTARDER ASSEMBLY ISB/H	24232	3099088	RESERVOIR	3929062	19230
581	CROSSHEAD,VALVE	24408	3945236	DRAINCOCK	3929064	19484
582	PISTON, SLAVE	24409	4024748	VALVE,PRESSURE RELIEF	3929065	19485
583	CAP,ADJUSTING NUT	24410	3945239	VALVE,CHECK	3929066	19486
584	SPACER,THREADED	24422	3945240	SWITCH,PRESSURE	3929067	19588
585	SLEEVE, HOUSING, ADJ.	24423	4024761	HARNESS,WIRING	3929068	19645
586	WASHER,PLAIN	24424	3945241	RELAY	3929069	18257
587	D-LASH ASSEMBLY W/CAP	24466	4024758	GASKET,EXH OUT CONNECTION	3929070	19590

#	Description	Jacobs #	Cummins #	Description	Cummins #	Jacobs #
588	WIRE, GROUND*	24523	3255804	GASKET,EXH OUT CONNECTION	3929071	19594
589	SOLENOID VALVE-12V D/L	24610	3871711	SLEEVE	3929072	20088
590	SOLENOID VALVE-12V S/L	24613	3871707	CLAMP,V BAND	3929073	19595
591	VALVE, SOLENOID 12V S/L	24614	4024759	JOINT,BALL	3929075	20748
592	SOLENOID VALVE-24V S/L	24616	3871708	CLIP	3929076	20750
593	SOLENOID VALVE-24V D/L	24617	3871709	CYLINDER,AIR	3929077	18395
594	HARNESS,WIRING*	24661	3411336	BRACKET,AIR CYLINDER	3929078	20787
595	EXTARDER ASSEMBLY ISB/F	24666	3099091	EXHAUST BRAKE TMVO CECO	3933128	22453
596	GASKET,EXH OUT CONNECTION	24764	3099094	FUEL PUMP SWITCH ASSEMBLY	3933129	22522
597	EXISB EXHAUST BRAKE ASSY	24881	3099084	SPRING, TENSION	3933130	24020
598	VALVE, SOLENOID	24899	3870850	SPRING, TENSION	3933131	24019
599	EXTARDER KIT MODEL EXISB	24923	3800441	VACUUM PRESSURE SWITCH ASS	3933132	22876
600	PNEUMATIC GROUP	24926	3806237	VACUUM SOLENOID ASSEMBLY	3933133	22875
601	PNEUMATIC GROUP	24928	3806238	WIRE HARNESS, TMVO	3933134	22455
602	KIT,WIRING HARNESS	24929	3803918	RELAY	3933135	22456
603	WASHER,SEALING*	24967	3406909	EXHAUST PIPE PRE-94	3933136	22763
604	EXB59 UK EXHAUST BRAKE KIT	25037	3284540	SPACER MOUNTING STUD	3936996	29775
605	ISB/H EXTARDER KIT	25044	3800442	EXHAUST BRAKE ASSY ISC/H	3944862	25611
606	ISB/F EXTARDER KIT	25045	3800443	CLAMP, V BAND	3944863	25631
607	BODY,ENGINE BRAKE VALVE	25057	3680937	GASKET	3944864	25629
608	Solenoid	25107	4089625	EXHAUST BRAKE ASSY ISC/F	3944865	25612
609	VALVE, SOLENOID 24V D/L	25108	4024760	CROSSHEAD,VALVE	3945236	24408
610	COVER,ACTUATOR	25141	3680933	CAP,ADJUSTING NUT	3945239	24410
611	VALVE,ENGINE BRAKE	25157	4026536	SPACER,THREADED	3945240	24422
612	BRAKE,ENGINE KIT	25160	3411467	WASHER,PLAIN	3945241	24424
613	BRAKE,SERVICE	25162	3411469	HARNESS,WIRING	3948278	33372
614	BRAKE,ENGINE*	25164	3411465	SPACER,ROCKER LEVER COVER	3948279	26304
615	SCREW,ADJUSTING	25166	3411473	SPACER,ROCKER LEVER COVER	3948280	25848
616	EXH BK ASSY ISB-TMVO CECO	25216	3800354	SPACER,ROCKER LEVER COVER	3948281	25849
617	GROUP, DASH SWITCH	25268	3800359	Brake Housing 490A Front 12v s/l	3963794	31793
618	ISB-TMVO CECO EX BRAKE KIT	25272	3800352	Brake Housing 490A Rear 12v s/l	3963795	31795
619	GASKET	25432	3870865	Brake Housing 490A Front 24v s/l	3963796	32658
620	GASKET GROUP, EXISC	25433	3800374	Brake Housing 490A Rear 24v s/l	3963797	32659
621	EXHAUST BRAKE GROUP EXISC	25565	3800392	Harness, Wiring ISL 12-1/2"	3964781	31800
622	EXHAUST BRAKE KIT EXISC	25566	3800372	ISC/ISL 03 T'mount F. Marmon Ebrak	3969392	32857
623	EXHAUST BRAKE ASSY ISC/H	25611	3944862	MODULE,CONTROL	4015672	28160
624	EXHAUST BRAKE ASSY ISC/F	25612	3944865	WASHER,PLAIN	4015687	28668
625	EXHAUST BRAKE KIT ISC/H	25613	3800414	ASSEMBLY,SLAVE PISTON	4015690	3753
626	EXHAUST BRAKE KIT ISC/F	25614	3800415	NUT,REGULAR HEXAGON JAM	4015691	2157
627	EXHAUST BRAKE GROUP	25615	3800416	HARNESS,MAIN	4015692	18542
628	EXHAUST BRAKE GROUP ISC/F	25616	3800417	HARNESS,ENGINE	4015693	18543
629	ISB/F EX BRAKE KIT SPARTAN	25628	3800386	SENSOR,SPEED	4015694	18544
630	GASKET	25629	3944864	CONNECTOR,OIL	4015695	2235
631	CLAMP, V-BAND	25630	4089340	HARNESS,POWER	4015696	18546
632	CLAMP, V BAND	25631	3944863	HARNESS,PRESSURE SWITCH	4015697	28161
633	EXISB EXHAUST BRAKE KIT	25637	3800387	HARNESS,OUTPUT/BRAKE	4015698	18548
634	EXHAUST BK KIT ISC/H	25641	3800388	GROUP,MOUNTING BRACKET	4015699	18563
635	EXHAUST BRAKE KIT ISC/F	25642	3800389	ASSEMBLY,SUPPLY HOUSING	4015705	3725
636	PISTON, MASTER	25842	4024750	ASSEMBLY,DRONE HOUSING	4015706	3726

#	Description	Jacobs #	Cummins #	Description	Cummins #	Jacobs #
637	SPACER,ROCKER LEVER COVER	25848	3948280	TERMINAL,SPADE	4015710	17400
638	SPACER,ROCKER LEVER COVER	25849	3948281	STUD,MOUNTING	4015711	18541
639	EXHAUST BRAKE ASSEMBLY, ISC/	25873	4089339	CROSSHEAD,EXHAUST VALVE	4015712	3763
640	BUSHING	25965	3413133	SUPPORT,HOUSING	4015713	3728
641	COVER,CONTROL VALVE	26170	3412330	CAPSCREW,CYLINDER HEAD	4015714	3759
642	KIT, MODEL 490 TUNE UP	26303	3800917	WASHER,FLAT	4015715	7215
643	SPACER,ROCKER LEVER COVER	26304	3948279	SPACER,END UNIT (UPPER)	4015716	3074
644	Brake Kit ISL 490	26306	4089655	SPACER,END UNIT (LOWER)	4015717	3752
645	VALVE,CHECK	26395	3413129	CLAMP,HARNESS	4015718	14908
646	SPRING,COMPRESSION	26397	3413130	COVER,CONTROL VALVE	4015719	3813
647	Brake Lever Sub-Assembly	26473	3413127	RETAINER, SLAVE PISTON SPRING	4024504	19139
648	COVER,ACTUATOR	26475	3413131	SWITCH,RELAY	4024724	18199
649	LEVER,ENGINE BRAKE	26554	3413098	PISTON, SLAVE	4024748	24409
650	RING,RETAINING	26555	3413132	SPRING, SLAVE PISTON	4024749	18209
651	ISB-TMVO EXT BRAKE ASSY CECO	26893	3870839	PISTON, MASTER	4024750	25842
652	HARNESS,WIRING	26921	3681579	SPRING, FLAT	4024751	18722
653	PISTON,ENGINE BRAKE SLAVE	26927	3413128	WASHER, PLAIN	4024752	21038
654	PISTON, ENG BRAKE SLEEVE	26977	4026905	SCREW, HEX HEAD CAP	4024753	18730
655	ISB-TMVO EXT BRAKE ASSY MOPAR	28087	3870840	SPRING, CONTROL VALVE	4024754	11434
656	MODULE,CONTROL	28160	4015672	RING, RETAINING	4024755	12291
657	HARNESS,PRESSURE SWITCH	28161	4015697	PISTON, ACCUMULATOR	4024756	12983
658	TUNE-UP KIT, ISX	28280	4025010	SPRING, ACCUMULATOR	4024757	12990
659	ISB-TMVO EXH BRAKE KIT CECO	28527	3800780	D-LASH ASSEMBLY W/CAP	4024758	24466
660	EXH BRAKE GROUP ISB-TMVO MO	28540	3800791	VALVE, SOLENOID 12V S/L	4024759	24614
661	ISB-TMVO EXH BRAKE KIT MOPAR	28587	3800792	VALVE, SOLENOID 24V D/L	4024760	25108
662	WASHER,PLAIN	28668	4015687	SLEEVE, HOUSING, ADJ.	4024761	24423
663	ISB/C EXH BRAKE KIT MONACO	28730	3800869	GASKET (3 PACKAGED)	4025000	13294
664	CLIP	29035	4026251	GASKET (3 PACKAGED)	4025001	2610
665	HSG. ASSY, MY 03 EXH BRAKE	29139	4089280	GASKET (3 PACKAGED)	4025002	14848
666	GASKET, EXHAUST OUTLET	29146	4089324	TUNE-UP KIT, ISX	4025010	28280
667	SPACER MOUNTING STUD	29775	3936996	CONTROL VALVE COVER - SIDE V	4025256	30979
668	WIRE HARNESS, ICON W/CLIP	29849	4059211	KIT, EXHAUST BRAKE, MY '03	4025268	31883
669	HARNESS, WIRING	29850	4059178	PISTON, MASTER	4025352	30383
670	SPRING, COMPRESSION	30362	4059315	RETAINER, SLAVE PISTON SPRING	4025404	19139
671	MANIFOLD ASSEMBLY	30365	3682343	CLIP	4026251	29035
672	PISTON, MASTER	30383	4025352	VALVE,ENGINE BRAKE	4026536	25157
673	CONTROL VALVE COVER - SIDE V	30979	4025256	SEAL,RECTANGULAR RING	4026537	1082
674	Brake Housing 490A Front 12v s/l	31793	3963794	SOLENOID	4026538	20997
675	Brake Housing 490A Rear 12v s/l	31795	3963795	PISTON, ENG BRAKE SLEEVE	4026905	26977
676	Harness, Wiring ISL 12-1/2"	31800	3964781	HARNESS, WIRING	4059178	29850
677	Harness, Wiring	31874	4089281	WIRE HARNESS, ICON W/CLIP	4059211	29849
678	Bracket, Solenoid	31882	4089284	SPRING, COMPRESSION	4059315	30362
679	KIT, EXHAUST BRAKE, MY '03	31883	4025268	HSG. ASSY, MY 03 EXH BRAKE	4089280	29139
680	SWITCH, STALK	31885	3870838	Harness, Wiring	4089281	31874
681	BRAKE KIT, ISM '02	31910	4089395	Bracket, Solenoid	4089284	31882
682	KIT, EXHAUST BRAKE, ISC/C	31972	4089338	GASKET, EXHAUST OUTLET	4089324	29146
683	Switch, Illuminated 4-Wire	32619	4089657	KIT, EXHAUST BRAKE, ISC/C	4089338	31972
684	Brake Housing 411D Front 12v s/l	32620	3103430	EXHAUST BRAKE ASSEMBLY, ISC/	4089339	25873
685	Brake Housing 411D Rear 12v s/l	32621	3103431	CLAMP, V-BAND	4089340	25630

#	Description	Jacobs #	Cummins #	Description	Cummins #	Jacobs #
686	Brake Housing 490A Front 24v s/l	32658	3963796	BRAKE KIT, ISM '02	4089395	31910
687	Brake Housing 490A Rear 24v s/l	32659	3963797	ISB 02 T'mount F. Marmon Ebrake Ass	4089590	32826
688	Brake Kit ISL Pegasus 12v/24v	32664	4089594	ISB 02 T'mount F. Marmon Ebrake Ki	4089591	32822
689	Brake Kit 490A 24v s/l	32665	4089627	ISB 02 In-line F. Marmon Ebrake Ass	4089592	32825
690	MY 04.5 Exhaust Brake Ass'y	32725	4089596	ISB 02 In-line F. Marmon Ebrake Kit	4089593	32821
691	Actuator	32727	4089658	Brake Kit ISL Pegasus 12v/24v	4089594	32664
692	Brake Housing 411C Front 12v d/l	32781	4906825	MY 04.5 Exhaust Brake Ass'y	4089596	32725
693	Brake Housing 411C Rear 12v d/l	32782	4906826	MY 04.5 Exhaust Brake Kit	4089597	33382
694	Brake Housing 411 Front 12v s/l	32783	4906837	ISC/ISL 03 In-line Ebrake Ass'y	4089622	32856
695	Brake Housing 411 Rear 12v s/l	32784	4906838	ISC/ISL In-line Exhaust Brake Kit	4089623	33002
696	Brake Housing 411 Front 24v s/l	32785	4906833	ISC/ISL 03 T'mount Exhaust Brake Ki	4089624	33004
697	Brake Housing 411 Front 24v s/l	32785	4906833	Solenoid	4089625	25107
698	Brake Housing 411 Rear 24v s/l	32786	4906834	Brake Kit 490A 24v s/l	4089627	32665
699	Brake Housing 411 Rear 24v s/l	32786	4906834	Brake Kit ISL 490	4089655	26306
700	Brake Housing 411 Front 24v d/l	32787	4906829	Switch, Illuminated 4-Wire	4089657	32619
701	Brake Housing 411 Front 24v d/l	32787	4906829	Actuator	4089658	32727
702	Brake Housing 411 Rear 24v d/l	32788	4906830	Brake Housing 411C Front 12v d/l	4906825	32781
703	Brake Housing 411 Rear 24v d/l	32788	4906830	Brake Housing 411C Rear 12v d/l	4906826	32782
704	ISB 02 In-line F. Marmon Ebrake Kit	32821	4089593	Brake Housing 411 Front 24v d/l	4906829	32787
705	ISB 02 T'mount F. Marmon Ebrake Ki	32822	4089591	Brake Housing 411 Front 24v d/l	4906829	32787
706	ISB 02 In-line F. Marmon Ebrake Ass	32825	4089592	Brake Housing 411 Rear 24v d/l	4906830	32788
707	ISB 02 T'mount F. Marmon Ebrake As	32826	4089590	Brake Housing 411 Rear 24v d/l	4906830	32788
708	ISC/ISL 03 In-line Ebrake Ass'y	32856	4089622	Brake Housing 411 Front 24v s/l	4906833	32785
709	ISC/ISL 03 T'mount F. Marmon Ebrak	32857	3969392	Brake Housing 411 Front 24v s/l	4906833	32785
710	ISC/ISL In-line Exhaust Brake Kit	33002	4089623	Brake Housing 411 Rear 24v s/l	4906834	32786
711	ISC/ISL 03 T'mount Exhaust Brake K	33004	4089624	Brake Housing 411 Rear 24v s/l	4906834	32786
712	HARNESS,WIRING	33372	3948278	Brake Housing 411 Front 12v s/l	4906837	32783
713	MY 04.5 Exhaust Brake Kit	33382	4089597	Brake Housing 411 Rear 12v s/l	4906838	32784